

Trademark Acknowledgements

IBM is a registered trademark of International Business Machines Corporation.
Microsoft, MS-DOS and GW-BASIC are registered trademarks of Microsoft Corporation.
Intel is a registered trademark of Intel Corporation.
CP/M is a trademark of Digital Research, Inc.
Lattice C is a trademark of Lattice Corporation.
Epson is a registered trademark of Seiko Epson Corporation.
Epson PX-16 is a trademark of Seiko Epson Corporation.
ESC/P is a trademark of Seiko Epson Corporation.
Utilities : Portions(C), Microsoft Corporation, 1985, 1986.
All rights reserved.

Notice

- * All rights reserved. Reproduction of any part of this manual in any form whatsoever without Epson's express written permission is forbidden.
- * The contents of this manual are subject to change without notice.
- * All efforts have been made to ensure the accuracy of this manual. However, should any errors be detected, Epson would greatly appreciate being informed of them.
- * The above notwithstanding, Epson can assume no responsibility for any errors in this manual or their consequences.

Copyright(C) 1987 by Seiko Epson Corporation
Nagano, Japan

**EPSON
PX-16**

SYSTEM GUIDE

PREFACE

<The purpose of this manual>

This manual explains the basic operations of the PX-16 and the specifications of the PX-16 operating system, firmware, interfaces, etc. The purpose of this manual is to let and software houses and third parties, who develop application software and hardware options for the PX-16, have enough information to develop the PX-16 systems.

The reader is assumed to be familiar with the following knowledge;

- Basic knowledge about MS-DOS
- General knowledge of assembler programming
- General knowledge on the instructions of CPU 8088

Basic operating instructions for the PX-16 are also included in this manual.

<Dealing with this manual>

There are four kinds of PX-16 manuals prepared.

- 1) PX-16 System Guide
- 2) PX-16 MS-DOS Reference Manual
- 3) PX-16 GW-BASIC Reference Manual
- 4) Operating Instructions for each optional units

All the necessary information to understand about the PX-16 system are explained in these four manuals. This manual, PX-16 System Guide, is written for the system developers with detailed information about the PX-16. However, any third party developers providing PX-16 based systems may need to include information from this manual in their own user's guide.

Please make sure to include the following information in the user's manual.

- Attention notes on "Introductions"
- Recharging procedure and notes on "2.1.3 Batteries and recharging"

Please include information from the following sections if needed.

- 2.1.1 Unit assembly
- 2.1.2 Switches
- 2.1.4 Starting and operation
- 3.4 The Disk Operating System
- Chapter 4 Interface ; explanations and notes on option units

Please make sure to get permission from Epson, when you make a copy of this manual.

<The construction of this manual>

This manual is a guide to the PX-16 system, with basic operating instructions and an explanation of the PX-16 functions. This manual consists of five chapters and an appendix.

Chapter 1 PX-16 General Overview

Describes features, appearance and system configurations of the Epson portable computer PX-16.

Chapter 2 Operating Instruction

Describes basic operating instructions including unit assembling, switch operations and recharging operations.

Chapter 3 Base Unit

Describes all the PX-16 system operations including memory access, system start and termination, interrupts, and slave CPU operations. This chapter also explains BIOS functions, I/O port accessing and power supply operations.

Chapter 4 Interface

Describes specifications and operations of all the interfaces; cartridge1 interface, cartridge2 interface, system bus, expansion interface, RS-232C interface, bar-code reader interface, printer interface, keyboard interface, touch keyboard interface and RAM board interface.

Chapter 5 Development Environment

Describes operations of application programs development including usage of development utilities and development tool.

Appendix

Describes the differences between HC boot mode and PC boot mode. Appendix also includes the PX-16 character-sets, sample programs and optional cable specifications and circuit diagrams.

<Before reading this manual>

(1) System component type

The PX-16 consists of a base unit and a variety of different optional units. The variety of optional units described in this manual are not sold in every country. Some are sold worldwide, but some are sold only on the specific market. Therefore, it doesn't mean you can get every unit, even if the explanation for the unit is described in this manual.

The composed units of PX-16 and the countries dealing in them are as follows.

name of units	Europe	Oceania	S.E.Asia	US/Canada	Japan
Base Unit	o	o	o		o
Standard Keyboard	o	o	o		JIS K/B
LCD80	o	o	o		o
LCD80/2	o	o	o		x
LCD40	o	o	o		o
CRT/FDD Cartridge	o	o	o		x
Universal Cartridge2	o	o	o		o
Blank Cartridge2	o	o	o		o
Cartridge Printer H	o	o	o		kana ver.
ROM Cartridge	(forPX-4)	(forPX-4)	(forPX-4)		(forHC-40)
RAM Cartridge	(forPX-4)	(forPX-4)	(forPX-4)		(forHC-40)
IC RAM Card Cartridge	x	x	x		o
Universal Cartridge1	o	o	o		o
Blank Cartridge1	o	o	o		o
384KB RAM Board	o	o	o		o
Disk Unit	o	o	o		o
TF-16	o	o	o		x
Asynchronous RS board	o	o	o		o
Development Tool	o	o	o		o
Japanese ROM set	x	x	x		o

(note) We don't know about the U.S. and Canada, yet.

name of units		Europe	Oceania	S.E.Asia	America	Japan
AC Adapter	H00KAW	x	x	Taiwan Korea		x
	H00KBW	o	o	HongKong Singapore		x
	H00KAJ	x	x	x		o

(2) Name of products in this manual

The following personal computers are mentioned in this manual.

IBM PC series (IBM PC, IBM PC/XT, IBM PC/AT)

They are the products of International Business Machine Corporation.

IBM 5550 series

They are the products of IBM Japan, sold only in Japan.

NEC 9800 series

They are the products of NEC Corporation, sold only in Japan.

EPSON PC series (EPSON PC, EPSON PCe, EPSON PC AX, etc.)

They are the products of Seiko Epson Corporation.

They are compatible machines of IBM PC series.

EPSON PCe is a compatible machine of IBM PC/new XT.

EPSON PC-286 series

They are the products of Seiko Epson Corporation, sold only in Japan.

(3) A word "KANJI" used in this manual is a name of the Japanese character set, enabled with a JIS (Japanese) K/B and a Japanese version of Cartridge printer H.

(4) Address Representation

Address are generally represented in hexadecimal notation. I/O addresses are prefixed by "P".

Examples:

0010H Memory address 10H

P10H I/O port address 10H

Note that the contents of I/O addressed may differ during read and write operations.

CONTENTS

Preface

Contents

Introduction

Chapter 1 PX-16 General Overview

1.1 . The PX-16 Epson Portable Computer	1 - 1
1.1.1 The Concept of the PX-16	1 - 1
1.1.2 PX-16 Features	1 - 2
(1) System component type configuration	1 - 2
(2) Expansibility	1 - 2
(3) Compact size	1 - 2
(4) Compatibility with EPSON PCe and IBM PC/XT	1 - 2
(5) Memory	1 - 2
1.1.3 PX-16 Operating System Features	1 - 3
(1) PC compatibility	1 - 3
(2) ROM DOS	1 - 3
(3) HC/PC boot	1 - 3
(4) Functions supported in HC Boot	1 - 3
1.2 . External Appearance	1 - 5
1.2.1 System configurations	1 - 5
1.2.2 Base unit	1 - 8
(1) Mother board	1 - 8
(2) Switches	1 - 8
(3) Interfaces	1 - 9
(4) Bottom surface	1 - 9
1.2.3 Options	1 - 10
(1) LCD80, LCD80/2	1 - 10
(2) LCD40	1 - 10
(3) Standard keyboard	1 - 11
(4) Touch keyboard	1 - 11
(5) CRT/FDD cartridge	1 - 12
(6) Cartridge printer H	1 - 12
(7) Asynchronous RS board	1 - 13
(8) 384KB RAM board	1 - 13
(9) Disk unit	1 - 14
(10) TF-16	1 - 15
(11) AC adapter	1 - 15
(12) Others	1 - 15

1.3 . System configuration	1 - 16
1.3.1 Overview	1 - 16
1.3.2 Hardware configuration	1 - 17
(1) Overview	1 - 17
(2) Hardware details	1 - 19
1.3.3 Software configuration	1 - 20
(1) Overview	1 - 20
(2) Configuration	1 - 21
(3) System ROM overview	1 - 21
1.4 . Memory	1 - 22
1.4.1 Memory configuration	1 - 22
1.4.2 Memory map	1 - 23
1.5 . Power supply	1 - 24
1.5.1 Overview	1 - 24
1.5.2 Power supply specifications	1 - 24
(1) Main battery	1 - 24
(2) Sub battery	1 - 24
(3) AC adapter	1 - 25
(4) Power lines	1 - 25

Chapter 2 Operating Instruction

2.1 . System operation	2 - 1
2.1.1 Unit assembly	2 - 1
(1) Assembly procedure	2 - 2
(2) Main battery Installation	2 - 3
(3) RAM board Installation	2 - 4
(4) Application ROM installation	2 - 6
2.1.2 Switches	2 - 9
(1) Power switch	2 - 9
(2) Reset switch	2 - 9
(3) System reset switch	2 - 10
(4) System clock select switch	2 - 10
(5) Cartridge 1 lock	2 - 11
(6) Backup switch	2 - 11
(7) DIP switches	2 - 12
(8) Jumper switches	2 - 15
2.1.3 Batteries and recharging	2 - 16
(1) Batteries	2 - 16
(2) AC adapter	2 - 19
(3) Recharging	2 - 20
2.1.4 Starting and operation	2 - 21
(1) System start	2 - 21
(2) Error messages	2 - 25
(3) National character sets	2 - 26
(4) Drive support	2 - 28

Chapter 3 Base Unit

3.1 . Base unit overview	3 - 1
3.1.1 Base unit configuration	3 - 1
3.1.2 Mother board configuration	3 - 1
3.2 . Memory	3 - 5
3.2.1 Memory overview	3 - 5
3.2.2 Memory access wait	3 - 7
3.2.3 ROM	3 - 8
(1) ROM sockets	3 - 8
(2) ROM format	3 - 9
(3) ROM access	3 - 11
3.2.4 RAM disk	3 - 12
(1) Overview	3 - 12
(2) RAM disk format	3 - 13
(3) RAM disk access	3 - 13
(4) Other	3 - 15
3.3 . System control	3 - 16
3.3.1 System start	3 - 16
(1) Overview	3 - 16
(2) Starting types	3 - 17
(3) Cold start	3 - 19
(4) Warm start	3 - 22
(5) Resume start	3 - 26
(6) Power-on self-tests	3 - 29
3.3.2 System Termination	3 - 33
(1) Overview	3 - 33
(2) System termination processing	3 - 34
(3) Setting the POWER Switch to OFF	3 - 35
(4) Power failure	3 - 35
(5) Auto Power-off	3 - 37
(6) BIOS Call	3 - 37
(7) Power off disable	3 - 38
3.3.3 Other control functions	3 - 40
(1) Alarm	3 - 40
(2) Ring	3 - 40
(3) Auto backlight off	3 - 41
(4) Printer power-off	3 - 41
(5) Disk power save feature	3 - 42
3.3.4 Interrupts	3 - 43
(1) Overview	3 - 43
(2) Extension method	3 - 44
(3) Extended Interrupt	3 - 45
(4) Extended Interrupt EOI	3 - 47
(5) NMI	3 - 48
(6) Cautions when using the 8259A interrupt controller	3 - 49

3.3.5 Slave CPU	3 - 50
(1) Slave CPU overview	3 - 50
(2) Hardware specification	3 - 51
(3) Slave CPU interface	3 - 57
(4) Command specifications	3 - 59
(5) Keyboard control	3 - 72
(6) Realtime clock functions	3 - 87
(7) Power supply control	3 - 88
(8) Reset	3 - 92
3.3.6 System variables	3 - 94
(1) Overview	3 - 94
(2) Area initialization	3 - 94
(3) Outline of area usage	3 - 94
(4) System variables list	3 - 95
3.4 . The Disk Operating System	3 - 128
3.4.1 MS-DOS	3 - 128
3.4.2 Device drivers	3 - 129
(1) Character devices	3 - 129
(2) Block devices	3 - 130
(3) Expansion device driver	3 - 132
3.4.3 CONFIG.SYS	3 - 133
(1) CONFIG.SYS search	3 - 133
(2) System configuration	3 - 134
(3) Multiple language support	3 - 135
3.4.4 EPSONDOS.COM	3 - 136
3.4.5 The command processor	3 - 137
3.5 . BIOS	3 - 141
3.5.1 Features of PX-16 BIOS	3 - 141
3.5.2 BIOS call chart	3 - 142
3.5.3 ROM BIOS details	3 - 145
3.6 . I/O register description	3 - 250
3.6.1 I/O address list	3 - 250
3.6.2 I/O register details	3 - 252
(1) I/O register list	3 - 252
(2) DMA controller	3 - 260
(3) Interrupt controller	3 - 262
(4) Timer/counter	3 - 263
(5) Peripheral I/O	3 - 265
(6) DMA page register	3 - 268
(7) NMI mask register	3 - 269
(8) Asynchronous RS-232C port (optional)	3 - 270
(9) HDD I/O	3 - 271
(10) Printer interface	3 - 272
(11) Monochrome CRT control register	3 - 273
(12) LCD80/color CRT control register	3 - 274
(13) Floppy disk drive interface	3 - 275
(14) Serial port (Standard)	3 - 276
(15) RAM disk I/O	3 - 277

(16) Barcode reader interface/LCD interface	3 - 279
(17) Cartridge 1 interface	3 - 282
(18) UART	3 - 284
(19) LCD80, LCD80/2 interface	3 - 288
(20) Expansion interrupt controller	3 - 290
(21) Touch panel interface	3 - 294
(22) RAM write protect	3 - 296
(23) ROM bank register	3 - 297
(24) Slave CPU interface	3 - 298
(25) DIP switch and other status	3 - 300
(26) Disk unit	3 - 303
3.7 . Power supply	
3.7.1 Power supply specifications	3 - 305
3.7.2 Power ON/OFF	3 - 308
3.7.3 The battery	3 - 309
(1) The main battery	3 - 309
(2) The sub-battery	3 - 309
3.7.4 Recharging and continuous use	3 - 310
(1) Recharging	3 - 310
(2) Current consumption	3 - 310

Chapter 4 Interfaces

4.1 . Overview	4 - 1
4.1.1 Overview	4 - 1
4.1.2 I/O addresses	4 - 2
4.2 . Cartridge 1 interface	4 - 3
4.2.1 Overview	4 - 3
4.2.2 Circuit diagrams	4 - 4
4.2.3 Signal lines	4 - 5
(1) Pin assignment	4 - 5
(2) Connector	4 - 5
(3) Description	4 - 6
4.2.4 Mode explanations	4 - 9
(1) Mode selection	4 - 9
(2) Signal differences by mode	4 - 10
(3) HS mode	4 - 13
(4) IO mode	4 - 20
(5) DB mode	4 - 24
(6) OT mode	4 - 29
4.2.6 Device codes	4 - 32
4.2.7 UART	4 - 34
(1) Overview	4 - 34
(2) I/O registers	4 - 34
4.2.8 Electrical characteristics	4 - 40
(1) DC characteristics	4 - 40
(2) I/O circuits	4 - 41

4.2.9 Options	4 - 42
(1) I/O register update method	4 - 42
(2) Cautions in direct control of cartridge 1	4 - 44
(3) Installation procedure	4 - 44
4.2.10 ROM cartridge	4 - 46
(1) Overview	4 - 46
(2) Specifications	4 - 46
(3) Recommended ROM	4 - 47
(4) ROM cartridge installation procedure	4 - 47
(5) ROM installation procedure	4 - 48
(6) Drive names	4 - 49
(7) Device code	4 - 50
(8) ROM memory map	4 - 50
(9) Block diagram	4 - 51
(10) I/O addresses	4 - 52
(11) Usage	4 - 53
(12) System support	4 - 56
4.2.11 RAM cartridge	4 - 57
(1) Overview	4 - 57
(2) Specifications	4 - 57
(3) ROM cartridge installation procedure	4 - 57
(4) Lithium battery replacement	4 - 58
(5) RAM cartridge formatting	4 - 59
(6) Drive names	4 - 59
(7) Device code	4 - 59
(8) RAM memory map	4 - 60
(9) Block diagram	4 - 61
(10) I/O addresses	4 - 62
(11) Usage	4 - 64
(12) System support	4 - 65
4.2.12 Cartridge printer H	4 - 66
(1) Overview	4 - 66
(2) Specifications	4 - 66
(3) Cartridge printer H installation procedure	4 - 67
(4) Paper set	4 - 68
(5) Installation of the ribbon cassette	4 - 70
(6) Basic printer operation	4 - 72
(7) Device code	4 - 72
(8) Block diagram	4 - 73
(9) I/O addresses	4 - 74
(10) Usage	4 - 76
(11) Printer control	4 - 77
(12) Printer control register	4 - 78
(13) Control codes	4 - 79
(14) Character set	4 - 86
(15) System support	4 - 88
(16) Cartridge printer 2 for PX-4/HX-40	4 - 89
4.2.13 Blank cartridge 1	4 - 90
(1) Overview	4 - 90

4.2.14 Universal cartridge 1	4 - 90
(1) Overview	4 - 90
(2) Assembly	4 - 90
4.3 Cartridge 2 interface	4 - 91
4.3.1 Overview	4 - 91
4.3.2 Circuit diagram	4 - 92
4.3.3 Signal conductors	4 - 94
(1) Pin assignment	4 - 94
(2) Connector	4 - 96
(3) Description	4 - 97
4.3.4 Electrical characteristics	4 - 101
(1) DC characteristics	4 - 101
(2) AC characteristics	4 - 102
(3) I/O circuits	4 - 106
4.3.5 LCD40	4 - 108
(1) Overview	4 - 108
(2) Specifications	4 - 108
(3) Installation procedure	4 - 108
(4) Block diagram	4 - 110
(5) I/O registers	4 - 111
(6) Relationship between VRAM and LCD panel	4 - 112
(7) Initialization and backup	4 - 112
(8) Fonts	4 - 112
(9) Pin assignment	4 - 113
(10) Connector	4 - 114
4.3.6 LCD80, LCD80/2	4 - 115
(1) Overview	4 - 115
(2) Specifications	4 - 115
(3) Installation procedure	4 - 116
(4) Block diagram	4 - 117
(5) LCD functions	4 - 118
(6) LCD/CRT Controller	4 - 119
(7) I/O register	4 - 125
(8) Font	4 - 137
(9) Initialization and backup	4 - 140
(10) Pin assignment	4 - 141
(11) Connectors	4 - 146
4.3.7 CRT/FDD cartridge	4 - 147
(1) Overview	4 - 147
(2) Installation procedure	4 - 147
(3) Block diagram	4 - 149
(4) LSI functions	4 - 149
(5) Display controller	4 - 151
(6) I/O register	4 - 152
(7) Initialization and backup	4 - 167
(8) Pin assignment	4 - 168
(9) Connectors	4 - 173

4.3.8 TF-16	4 - 174
(1) Overview	4 - 174
(2) Specifications	4 - 174
(3) Installation procedure	4 - 175
(4) Drive name	4 - 176
(5) Formatted disk capacity	4 - 176
(6) Block diagram	4 - 177
(7) Pin assignment	4 - 178
(8) Connector	4 - 178
(9) Description	4 - 179
(10) I/O circuits	4 - 180
4.3.9 Blank cartridge 2	4 - 181
(1) Overview	4 - 181
(2) Installation procedure	4 - 181
4.3.10 Universal cartridge 2	4 - 182
(1) Overview	4 - 182
(2) Assembly	4 - 182
4.4 . RS-232C interface	4 - 184
4.4.1 Overview	4 - 184
4.4.2 Circuit diagram	4 - 185
4.4.3 Signal lines	4 - 186
(1) Pin assignment	4 - 186
(2) Connector	4 - 186
4.4.4 Electrical characteristics	4 - 187
(1) DC characteristics	4 - 187
(2) I/O circuit	4 - 187
4.4.5 I/O addresses	4 - 188
4.4.6 Function overview	4 - 199
4.5 . Barcode reader interface	4 - 200
4.5.1 Overview	4 - 200
4.5.2 Circuit diagram	4 - 202
4.5.3 Signal lines	4 - 203
(1) Pin assignment	4 - 203
(2) Connector	4 - 203
(3) Description	4 - 203
4.5.4 Electrical characteristics	4 - 204
(1) DC characteristics	4 - 204
(2) I/O circuit	4 - 204
4.5.5 BARCODE.COM	4 - 205
(1) Overview	4 - 205
(2) Features of BARCODE.COM	4 - 205
(3) Software support	4 - 205
4.5.6 I/O registers	4 - 206

4	4.6 . System bus	4 - 212
4	4.6.1 Overview	4 - 212
4	4.6.2 Circuit diagram	4 - 213
5	4.6.3 Signal lines	4 - 215
6	(1) Pin assignment	4 - 215
6	(2) Connector	4 - 217
7	(3) Description	4 - 218
8	4.6.4 Electrical characteristics	4 - 221
8	(1) DC characteristics	4 - 221
9	(2) AC characteristics	4 - 222
0	(3) I/O circuit	4 - 225
1	4.6.5 Disk unit	4 - 230
1	(1) Overview	4 - 230
1	(2) Specifications	4 - 231
2	(3) Installation procedure	4 - 232
2	(4) Drive name	4 - 235
2	(5) HDD logical format	4 - 236
4	(6) Disk access when both TF-16 and Disk unit are connected	4 - 237
4	(7) Differences between TF-16 and Disk unit	4 - 237
5	(8) I/O addresses	4 - 238
6	(9) Hard disk BIOS	4 - 247
6	4.7 . Printer interface	4 - 263
6	4.7.1 Overview	4 - 263
7	4.7.2 Circuit diagram	4 - 264
7	4.7.3 Signal lines	4 - 265
8	(1) Pin assignment	4 - 265
8	(2) Connector	4 - 265
9	(3) Description	4 - 266
9	4.7.4 Electrical characteristics	4 - 267
0	(1) DC characteristics	4 - 267
0	(2) I/O circuits	4 - 267
2	4.7.5 I/O registers	4 - 268
3	4.8 . Expansion interface	4 - 271
3	4.8.1 Overview	4 - 271
4	4.8.2 Circuit diagram	4 - 272
4	4.8.3 Signal lines	4 - 274
5	(1) Pin assignment	4 - 274
5	(2) Connector	4 - 276
6	(3) Description	4 - 277
6	4.8.4 Electrical characteristics	4 - 280
7	(1) DC characteristics	4 - 280
7	(2) AC characteristics	4 - 281
8	(3) I/O circuits	4 - 285
8	4.8.5 Asynchronous RS board	4 - 287
9	(1) Overview	4 - 287
9	(2) Installation procedure	4 - 288
0	(3) Block diagram	4 - 291
0	(4) Jumpers	4 - 291
1	(5) Expansion functions	4 - 292

(6) DC characteristics	4 - 292
(7) I/O registers	4 - 293
(8) Pin assignment	4 - 305
4.8.6 Development tool	4 - 308
(1) Overview	4 - 308
(2) Installation procedure	4 - 309
(3) Usage of development tool	4 - 312
(4) I/O addresses	4 - 312
(5) Pin assignment	4 - 323
4.9 . Keyboard interface	4 - 327
4.9.1 Overview	4 - 327
4.9.2 Circuit diagram	4 - 328
4.9.3 Signal lines	4 - 329
(1) Pin assignment	4 - 329
(2) Connector	4 - 329
(3) Description	4 - 330
4.9.4 Keyboard control	4 - 331
4.9.5 I/O addresses	4 - 332
4.9.6 Standard keyboard	4 - 333
(1) Overview	4 - 333
(2) Installation procedure	4 - 333
(3) Key scan codes	4 - 337
(4) International character sets	4 - 387
(5) Keyboard status transition	4 - 388
(6) Pin assignment	4 - 389
4.9.7 Touch keyboard (numeric keypad)	4 - 390
(1) Overview	4 - 390
(2) Installation procedure	4 - 390
(3) Key scan codes	4 - 391
(4) Pin assignment	4 - 392
4.10 Touch keyboard interface	4 - 393
4.10.1 Overview	4 - 393
4.10.2 Circuit diagram	4 - 394
4.10.3 Signal lines	4 - 396
(1) Pin assignment	4 - 396
(2) Connectors	4 - 397
4.10.4 Electrical characteristics	4 - 398
(1) DC characteristics	4 - 398
(2) AC characteristics	4 - 399
(3) I/O circuit	4 - 400
4.10.5 Touch keyboard	4 - 401
(1) Overview	4 - 401
(2) Installation procedure	4 - 402
(3) Block diagram	4 - 405
(4) I/O addresses	4 - 406
(5) Touch keyboard scan	4 - 407

	(6) Key interrupt	4 - 412
	(7) Touch panel electrical discharge	4 - 412
	(8) Example of scan flow	4 - 413
	(9) Display	4 - 414
	(10) OS support	4 - 415
	(11) The numeric keypad	4 - 415
4.11	RAM board interface	4 - 416
4.11.1	Overview	4 - 416
4.11.2	Circuit diagram	4 - 417
4.11.3	Signal lines	4 - 418
	(1) Pin assignment	4 - 418
	(2) Connector	4 - 419
	(3) Description	4 - 420
4.11.4	Electrical characteristics	4 - 422
	(1) DC characteristics	4 - 422
	(2) AC characteristics	4 - 422
4.11.5	I/O addresses	4 - 423
4.11.6	384KB RAM board	4 - 427
	(1) Overview	4 - 427
	(2) Installation procedure	4 - 427
	(3) RAM disk capacity	4 - 431
	(4) RAM disk setting	4 - 431
	(5) RAM refresh	4 - 432
	(6) Drive names	4 - 433

Chapter 5 Development environment

5.1	PTL	5 - 1
5.1.1	Overview	5 - 1
5.2	System configuration	5 - 2
5.3	XTERM	5 - 8
5.3.1	Overview	5 - 8
5.3.2	Terminst	5 - 8
5.3.3	Execution of XTERM	5 - 10
5.3.4	Terminal mode	5 - 11
5.3.5	Filink mode	5 - 13
5.4	Development on GW-BASIC	5 - 15
5.4.1	Development procedure	5 - 15
5.4.2	Debugging operation	5 - 17
5.4.3	Memory map for debugging mode	5 - 18
5.5	Development in other languages	5 - 19
5.5.1	Development procedure	5 - 19
5.5.2	Debugger operation	5 - 21
5.5.3	Memory map for debugging mode	5 - 23

5.6 . ROMFORM	5 - 24
5.6.1 Overview	5 - 24
5.6.2 Function	5 - 24
5.6.3 ROM disk format	5 - 26
5.6.4 Operation	5 - 27
(1) Execution	5 - 27
(2) Operation	5 - 27
5.6.5 Error messages	5 - 32

Appendix

- A-1 HC boot and PC boot
- A-2 Cautionary points regarding external expansion board design
- A-3 Character code table
- A-4 Optional cables
- A-5 Expansion ROM
- A-6 Differences between EPSON PCe and PX-16 with PC boot
- A-7 Sample program lists

INTRODUCTIONS

5

INTRODUCTIONS

<Environment on System Use>

The PX-16 is durably designed to protect important data and programs. However, as the PX-16 is a system component type precision machine consisting of electronic parts, please follow the instructions given below when the PX-16 is in use.

1. Be careful not to bump or drop the PX-16. Handle with care especially when the system is being carried in the carrying case or in the brief case.
2. Do not leave or set the PX-16 system at any place subject to direct sunlight or dust.
3. Do not leave the PX-16 system in an automobile or any other place subject to high temperature or humidity.

Use the PX-16 system in the following environment.

Temperature:	in usage	5 - 35 degrees°C
	in safekeeping	-20 - 50 degrees°C
Humidity:	in usage	10% - 80%
		(without dew condensation)
	in safekeeping	10% - 80%
		(without dew condensation)

4. Do not use the PX-16 system near a strong magnetic field, like near a television set, a radio, or stereo set.

With LCD80, LCD80/2, LCD40 or Touch Keyboard

1. Be careful not to scratch or damage the LCD with a sharp object such as a pen.
2. Be careful not to break the LCD by bumping or dropping the PX-16 system.
3. Do not use the PX-16 system in a place subject to extremely high or low temperature. Reaction of the LCD display may become dull in low temperature and LCD display may darken in high temperature. (It comes back to normal stage in normal temperature.)

With Disk Unit

1. Use the PX-16 system with the Disk Unit on a flat hard surface.
2. Move the PX-16 system with the Disk Unit carefully so that the Disk Unit is not damaged, especially when a HDD is installed.
3. Never bump or drop the PX-16 system with the Disk Unit when carrying in a carrying case. Please carefully set the carrying case on a flat hard surface.

<Cautions on operation>

1. Turn the main power off when assembling or disassembling the system. (see 2.2.1)
2. Do not touch electronic parts if not needed. (see 2.2.1)
3. Turn the main power off when any of the optional units needs to be taken out or installed.
4. Make sure that the drive access indicator is set to off, when the system with the Disk Unit or TF-16 is to be turned off.
5. Notice that all the data is destroyed when an optional 384KB RAM board, keyboard or touch keyboard is removed or installed. Save all important data in the RAM disk to the external storage device.