

Message	Meaning
Unrecognized Destination	Check command line for valid destination.
Use: STAT d: = RO	An invalid STAT drive command was given. The only valid drive assignment in STAT is STAT d: = RO.
VERIFY ERROR: -{filespec}	When copying with the V option, PIP found a difference when rereading the data just written and comparing it to the data in its memory buffer. Usually this indicates a failure of either the destination disk or drive.
XSUB ACTIVE	XSUB has been invoked.
XSUB ALREADY PRESENT	XSUB is already active in memory.
Your input?	If CP/M cannot find the command you specified, it returns the command name you entered followed by a question mark. Check that you have typed the command line correctly, or that the command you requested exists as a .COM file on the default or specified disk.

# Index

## A

ABORTED I-1  
 AC adapter 2-1  
 Acoustic coupler 3-76, 4-26, 4-42  
     connection 4-42  
 A/D converter see Analog/Digital converter ADCVRT subroutine 5-34  
     example of use H-1  
 Afn 3-5  
 ALARM 2-22, 2-27, 2-47  
     setting 2-27, 2-29  
 <ALARM MSG> 2-28  
 ALARM string 2-27  
 Ambiguous file names 3-5  
 Analog/Digital converter 1-9, 4-37  
     example of use H-1  
     location 4-37  
 Arrow keys 2-14  
 Alphanumeric keys 2-11  
 ASCII codes E-1  
     printers and E-2  
     table E-3, E-4, E-5, E-6, E-7, E-8  
 ASM (8080 assembler) 3-92  
     error messages I-1  
 Assembly language programming 3-92, 5-1  
 AUTO POWER OFF time 2-42, 2-47, 3-61  
 Auto repeat keys 2-11  
     controlling using ESC sequence A-17  
 AUTOSTART 2-23, 2-31, 2-32, 2-47  
 AUTOSTART string 2-32  
     rules for setting up 2-34

## B

Backspacing 2-15  
 BAD DELIMITER I-2  
 Bad load I-2  
 Bar code reader 4-37  
 BASIC 1-10, 2-20  
     CALL and BIOS calls H-4

- from the MENU 2-40
- Microcassette and 4-10
- programs and the MENU 2-40, 2-41
- resident 2-35
- restarting from CP/M command line 3-28
- screen modes in 2-50
- setting parameters from 2-48
- Submit files from 3-57
- Basic Disk Operating System (BDOS) 2-21
- BAT: 3-14, 5-2
- Battery C-1
  - charging 2-2, C-1
  - charge problems C-2
  - charge Time 2-3
  - insertion 2-2
  - length of use on a charge 2-2
  - replacing C-4
  - Switching off during extended storage C-2
- BDOS 2-21, 5-1
  - function calls 5-4
  - location of 5-8
- Bdos error on d: I-2
- Bdos error on d: bad sector I-2
- Bdos error on d: file R/O I-2
- Bdos error on d: select I-2
- BEEP subroutine 5-20
- BIOS 5-1
  - example programs Appendix H
  - interface 5-9
  - subroutine functions 5-10
  - table of entry addresses 5-10
- Blank screen 2-3, 2-20
- Books about CP/M 3-93
- BOOT subroutine 5-11
- Break "x" at c I-2
- BS key 2-15
- Buffer (keyboard) 2-12

## C

- CALLX subroutine 5-32
- Cannot close I-3
- Cannot read I-3
- CAPS LOCK 2-12
- CAPS LED 2-12
- Carriage return 2-14
- Carriage handle 1-5

- CCP 2-21, 5-1
- Central processor units 1-8
- Change device assignments 3-46
- Changing character sets 3-74
- Changing disks 3-8
- Changing parameters (see System Display and CONFIG) 2-49
- Changing Roms 3-9
- Changing Tapes 3-9
- Character deletion commands 3-10
- Character generator ROM A-5
- Character printing using ESC sequence A-14
- Character set (see also DIP switch setting) 2-47, 3-74, A-6
- Charging battery 2-2, C-1
- CHARGE BATTERY C-1
- Charge time 2-3
- Checksum error I-3
- Clear line from cursor to end A-7
- Clearing
  - the screen 2-15, 2-52, A-5
  - from cursor to end A-7
- Clock module 2-21, 2-27
- CLR key 2-15
- COM file 3-4
- Command file 3-4
- Command buffer overflow I-3
- Command too long I-4
- Communication using PIP 3-38
- Communications 3-75
  - cable for PX-8 to PX-8 4-26
  - with QX-10 computer 3-79
- CON: 3-13, 5-2
- CONFIG program 2-8, 2-16, 2-18, 2-23, 2-29, 2-50, 3-62
  - parameters changed by 2-47, 3-62
- CONIN subroutine 5-12
- CONOUT subroutine 5-12
- Console Command Processor(CCP) 2-21
- Console ESCAPE sequences A-1
- CONST subroutine 5-11
- Control codes 2-12
- Continue mode 2-19, 2-20, 2-32
- COPYDISK 3-91
- Copying files (see PIP) 3-35
- Copying Floppy Disks 3-91
- Correct error I-4
- Counter of tape 4-5
- CP/M 1-10, Chapter 3
  - built in commands 3-16
  - configuration 5-1
  - disk utilities 3-91

- finding out more 3-93
- function keys assignments 3-62
- function key display 3-64
- program utilities 3-91
- CP/M command line 2-20
  - and character 2-13
  - and cursor keys 2-14
  - and MENU 2-38
  - keyboard characters accepted by 3-10
  - printing from 3-12
  - turning to from MENU 2-42
- CPUs 1-9
- CRT: 3-15
- CTRL keys 2-12
- CTRL key used to switch off in continue mode 2-19
- CTRL-C 2-12
  - and warm starts 3-9
  - CTRL-HELP 2-15
  - CTRL-L 2-15, 2-52
  - CTRL-M 2-14
  - CTRL-P to toggle printer 3-12
  - CTRL-STOP 2-14
- Current drive 2-47
- Cursor changing 3-64
- Cursor keys and CP/M 2-14
- Cursor keys 2-7, 2-14
- Cursor
  - move to position on screen A-6
  - redefining using ESC sequence A-15
  - switching off A-5
  - switching on 3-64, A-5
- Cursor type 2-47, 3-64
  - changing with ESC sequence A-15

## D

- Date setting 2-7, 2-47, 3-65
- Day setting 2-8, 2-47
- DDT 3-91
- DEL key 2-15
- Default settings 2-47
- Deleting characters 2-15, 3-10
  - lines 3-11
- Destination is R/O I-4
- Device assignments 3-46, 3-48
- DIP switch 2-3
- DIR 3-6, 3-17

- Directory full I-4
- Directory of disk 3-6, 3-17
  - pausing 3-20
  - printing 3-20
  - stopping 3-20
- Disk assignments 2-47, 3-66
- Disk characteristics 3-47
- Disk drive allocation 3-66
- Disk drive connection 4-29
- Disk full I-4
- Disk read error I-4
- Disk write error I-4
- DISKROV 5-19
- DISKTBL 5-19
- Displaying contents of a file using TYPE 3-30
- Display control commands 3-11
- Display does not appear 2-3
- Display screen 1-8
- DRINIT 4-6
- Drive, current 2-47
- Drive name assignments Appendix B
- Drive names 3-6
- Dual screen 2-56
- DUMP 3-92

## E

- ED 3-91
- ERA 3-16, 3-21
- Erasing files from directory 3-21
  - of microcassette tape 3-23
- Error bad parameter I-4
- Error cannot open source I-5
- Error cannot close file I-5
- Error cannot open source I-5
- Error disk read I-5
- Error disk write I-5
- Error inverted load address I-5
- Error no more directory space I-5
- Error on line nn I-5
- ESC key 2-12, 2-14
- ESCAPE 2-14
  - sequences 2-47, A-1
  - sequences examples of use A-4
- Executing a series of commands 3-54
- Extension to files 3-3
  - examples of 3-4

## F

- FCB 5-3
- Files and Filenames 3-3
  - characters allowed 3-3
  - control block (FCB) 5-3
  - size and attributes 3-50, 3-51
  - storage devices 4-1
- File exists 1-5
- File is read only 1-6
- File not found 1-6
- Filename required 1-6
- File types on MENU 2-36, 2-39, 2-47
- FILINK 3-32, 3-88
- Floppy Disk
  - drives 4-21
  - connection 4-29
- Folding legs 1-7
- Forgetting Password 2-26
- Format RAM disk 2-10
- FORMAT for disks 3-91
- Freezing screen window 2-15
- FUNCFLG 5-12

## G

- GETPFK subroutine 5-14
- GO 2-41
- GRPH key 2-13
- Graphics
  - characters 2-13, E-2
  - and printer 4-33
- Graphics screen 2-57

## H

- hhhh? = dd error 1-6
- Halting display temporarily 2-14
- Halting the computer temporarily 2-18
- HELP 2-14
- Hide files on directory 3-49
- HOME key 2-16
- HOME disk subroutine in BIOS 5-16
- How to use the manuals v

## I

- Initialization 2-19
  - to overcome Password 2-26
- Initialization questions 2-7
  - reset 2-46
- INS 2-15
- Inserting characters 2-15
- Inserting battery 2-2
- Insufficient memory 1-6
- Intelligent RAM disk 2-5, 2-9
- Interfacing to other devices 4-1
- International characters table E-9
- Invalid error messages 1-6, 1-7
- IOBYTE 2-47, 5-2
- Italian characters 1-7, 3-74

## J

- JUMPX subroutine 5-32

## K

- Key response 2-12
- Keyboard and CP/M 3-10
  - buffer clearing with ESC sequences A-18
  - cover 1-6
  - layouts 1-6
  - layouts altering 2-3
  - operation 2-11

## L

- Legs positioning 1-7
- LCD (Liquid Crystal Display) 1-8, 2-50
- LCD opening 1-8
- LDIRX subroutine 5-31
- LED A-10, A-11
- LIGHTPEN subroutine 5-33
- Line termination commands 3-11
- Line drawing using ESC sequence A-12
- LIST subroutine 5-13
- LISTST subroutine 5-14
- LOADX subroutine 5-31

Logical and physical devices 3-14  
tables 3-16, 5-2  
Lower case 2-12  
LPT: 3-15, 5-2  
LST: 3-14, 5-2

## M

Main processor 1-9  
MASKI subroutine 5-34  
<MCT MODE> 2-43  
MCMTX subroutines 5-36  
Memory Map Appendix F  
MENU  
screen 2-10, 2-20, 2-21, 2-22, 2-23, 2-36, 2-47  
activation conditions 2-42  
command line 2-37  
default settings 2-47  
header 2-37  
interruption off 2-42  
reverting to CP/M command line 2-42  
setting files types to be displayed 2-36, 2-39  
termination of 2-42  
using 2-37  
using WAKE and AUTOSTART strings with 2-34  
Microcassette 4-1  
BASIC and 4-10  
care of 4-2  
changing tapes 2-44, 3-9  
checking if tape is mounted 4-9  
counter 2-43, 2-44  
deck 1-9  
directory 2-44, 3-19, 3-23, 4-4, 4-9  
directory initialization 4-6  
drive name 4-1  
EJECT button 4-6  
erasing files 3-23, 4-5  
executing a program from 4-10  
insertion of tape 4-2  
loading 4-7  
maximum files 1-9, 4-2  
manual setting 2-43, 4-4  
mode 2-43  
mounting 2-44, 4-4, 4-7  
non-stop and stop modes 2-43, 4-11  
removing 2-44, 4-5, 4-7, 4-8, 4-9  
selection and use 4-2

stop 2-44  
STOP in an emergency 2-44  
summary of operation 4-14  
verify and non verify mode 2-43  
Microcassette I/O System (MIOS) 2-21  
Microcassette Tape Operating System (MTOS) 2-21, 4-1  
MIOS 2-21, 5-1  
Modem 4-26  
MOUNT see under Microcassette  
MTOS 2-21, 5-1

## N

NO directory space I-7  
No display 2-3  
NO FILE 3-7, I-8  
No space I-8  
No sub file present I-8  
Non-stop mode of microcassette 2-43, 4-11  
Not deleted I-8  
Not found I-8  
NUM 2-13  
Numerical keypad 2-13

## O

Object Code 3-4  
Operating systems 1-10  
Operating System modules 2-21  
Operating the Computer Chapter 2

## P

Password 2-20, 2-21, 2-22, 2-24, 2-34, 2-47  
Password removal 2-25  
Password forgetting 2-26  
PAUSE 2-14  
PF keys 2-16  
PIP 3-32, 3-34  
optional parameters 3-37  
with printer 4-32  
Point of graphics screen set using ESC sequence A-13  
Portable Calc 1-11, 3-33  
Portable Scheduler 1-11  
Portable Wordstar 1-11, 3-33

- and SUBMIT files 3-58
- Power failure 2-19
- POWEROFF routine 2-19, 5-11
- Power on automatically, see WAKE
- Power BIOS subroutines 5-11
- Power switch 2-18
- Precautions on using the AC adapter 2-1
- Precautions on using the Px-8 2-1
- Printer 4-32
  - ASCII codes E-2
  - cable 4-26
  - examples of use 4-32
  - output port 2-47, 3-67, 3-73
  - unintelligible output 4-31
- Printing
  - from CP/M command line 3-12
  - contents of a file using PIP 3-35
  - contents of a file using TYPE 3-30
- Programmable function keys 2-16
  - and CP/M 3-10, 3-62
  - disabling and enabling A-11
  - displaying 3-64
  - display switching using ESC sequence A-15
  - and Microcassette Tape 4-5
- Protecting files
  - from other users 3-31
  - make Read/Only 3-48
  - removing protection 3-49
- PSET subroutine 5-15
- PTP: 3-14, 5-2
- PTR: 3-14, 5-2
- PUN: 3-13, 5-2
- PUNCH subroutine 5-13
- PUTPFK subroutine 5-14

## Q

- Quit not found I-9
- QX-10 Terminal mode 3-79, 3-81
- QX-10 communication 3-79

## R

- RAM DISK 2-8, 2-23, 3-66
  - additional 4-19
  - default 2-9, 2-47
  - format 2-10

- see also Intelligent RAM disk
- RDR: 3-13, 5-2
- RDVRAM subroutine 5-33
- READ subroutine 5-18
- READER subroutine 5-13
- Real screen 2-50
- Receiving files 3-83, 3-89
- Record too long I-9
- Removing Password 2-25
- REN 3-16, 3-25
- Renaming files 3-25
- Resetting the system 2-5, 2-46
- Reset altering keyboard 2-5
- Reset summary table 2-47
- Reset CPU 2-5
- Reset complete CPU 2-5
- Reset simple 2-46
- Reset sub CPU 2-5, 2-19, 2-46
- Response of keys 2-12
- Restart mode 2-19, 2-20, 2-32
- Restarting programs 3-28
- RETURN key 2-14
- RETURN ASCII code 2-14
- ROMs and ROM sockets 4-17
  - changing 3-9, 4-15
  - containing data or BASIC programs 4-18
- RS-232C 2-47, 3-67, 4-22
  - BIOS routines 5-20
  - cables 4-26
  - changing parameters 3-68
  - communications with 3-75, 4-22
  - connection 4-24
  - default settings 4-23
    - and printer 4-23
    - pin assignments 4-25
- RSCLOSE subroutine 5-21
- RSIN subroutine 5-22
- RSINST subroutine 5-21
- RSIOX subroutines 5-23
  - RSIOX(CLOSE) 5-24
  - RSIOX(CTLIN) 5-26
  - RSIOX(ERSTS) 5-27
  - RSIOX(GET) 5-25
  - RSIOX(INSTS) 5-24
  - RSIOX(OPEN) 5-23
  - RSIOX(OUTST) 5-25
  - RSIOX(PUT) 5-26
  - RSIOX(SENS) 5-27
  - RSIOX(SETCTL) 5-27

RSOPEN subroutine 5-21  
RSOUTST subroutine 5-22  
RSOUT subroutine 5-22

## S

SAVE 2-20, 3-16, 3-27  
Save a block of memory 3-27  
SAVE GO.COM 2-41, 3-28  
Screen guide to using 2-50  
Screen blank on switching on 2-3, 2-19  
Screen saving to disk H-6  
Screen Dump 2-17, 2-21, 2-45  
    and DIP switch setting 2-4, 4-33  
    using ESC sequence A-7  
    and graphics characters 4-33  
    halting 2-45  
Screen mode 3-69  
    changing 3-70  
    changing with ESC sequence A-13  
    default 2-47  
Screen mode 0 2-51  
Screen mode 1 2-55  
Screen mode 2 2-56  
Screen mode 3 2-57  
Screen printing - halting 2-14  
SCRN key 2-15, 3-12  
SCRNDUMP subroutine 5-16  
Scrolling screen 2-52  
Scrolling screen using ESC sequences A-8, A-9, A-10  
Secret mode A-7, A-8  
SECTAN subroutine 5-19  
SELDSK subroutine 5-16  
Sending files 3-84, 3-89  
Serial interface 2-47, 3-72, 4-29  
    connector 4-29  
    pin assignments 4-30  
Series of commands 3-55  
SETDMA subroutine 5-18  
SETSEC subroutine 5-17  
Setting the ALARM 2-27  
SETTRK subroutine 5-17  
Shift key setting using ESC sequence A-19  
SHIFT IN/SHIFT OUT 4-22, 5-21  
SLAVE  
    subroutine 5-33  
    example of use H-6

Slave processor 1-9  
Source Code 3-4  
Space on disk 3-52  
Spanish characters 1-7, 3-74  
Speaker 4-34  
    BIOS subroutine 5-20  
    external jack location 4-34  
    tape through 2-43  
Special keys 2-14  
Split screen 2-55  
Start not found I-9  
Starting up the Px-8 2-1  
STAT program 2-38, 3-32, 3-45  
    summary of commands 3-53  
STOP key 2-14  
Stop mode of microcassette 2-43, 4-11  
Storage C-2  
Storing on second virtual screen 2-54  
STORX subroutine 5-31  
Sub CPU 1-9  
SUBMIT 3-32, 3-54  
    comments in 3-58  
    files from BASIC 3-57  
    files from Wordstar 3-58  
    keyboard input see XSUB  
Switch keys 2-12  
Switching the PX-8 on and off 2-18  
System activator 2-21  
System Bank 5-30  
System Bus Interface 4-39  
System Display 2-15, 2-21, 2-22  
    parameters changed by 2-47  
System file not accessible I-9  
System Interface 5-1  
System prompt 3-6

## T

TAB 2-15  
TERM 3-32, 3-77  
Terminal mode 3-82  
TIMEDAT  
    subroutines for clock 5-28  
TIMEDAT(ALARM DISABLE) 5-29  
TIMEDAT(ALARM ENABLE) 5-29  
TIMEDAT(READ ALARM) 5-30  
TIMEDAT(READ TIME) 5-29

TIMEDAT(SET ALARM) 5-29  
TIMEDAT(SET TIME) 5-29  
Time setting 2-7, 3-65  
Too many files I-9  
Tracking mode 2-15, 2-50, 2-51  
    setting using ESC sequences A-9  
TTY: 3-15, 5-2  
TYPE 3-16, 3-27

## U

UC1: 3-15, 5-2  
Ufn 3-5  
UL1: 3-14, 5-2  
Unambiguous file names 3-4  
Universal Unit 4-38  
Unpacking notes 1-1  
UP1: and UP2: 3-14, 5-2  
Upper case 2-12  
UR1: and UR2: 3-15, 5-2  
Use: STAT error I-10  
User bank 5-30  
USER BIOS 2-9, 2-23, 2-47, 3-73  
USERBIOS subroutine 5-36  
User defined characters 2-13, 2-47  
    changed by reset 2-48  
    setting with ESC sequence A-16  
USER 3-16, 3-31  
    status 3-52  
Utilities 1-10, 3-32

## V

Verify and non-verify modes of microcassette 2-43, 4-11, 4-13  
Verify error I-10  
Virtual screens 2-50  
    changing between 2-54, 3-12  
    changing with ESC sequence A-14  
    description of using 2-51  
    lines in screen mode 0, 3-70  
    lines in screen mode 1, 3-71  
    lines in screen mode 2, 3-71  
    lines in screen mode 3, 3-72

## W

WAKE 2-22, 2-27  
    rules for setting 2-34  
    setting 2-30  
Wake treated as an Alarm 2-25, 2-32  
Warm start 2-14, 3-9, 4-24  
WBOOT 5-11  
    how to find 5-8  
Wildcards  
    and ALARM setting 2-29  
    and CP/M files 3-5  
    problems if used with ERA 3-22  
Winding tape 2-43  
Window on virtual screen  
    default setting 2-47  
    freezing 2-15  
    moving with ESC sequence A-15, A-16  
WRITE subroutine 5-18

## X

XON/XOFF 4-22, 5-21  
XSUB 3-32, 3-54, 3-60  
    for keyboard input in SUBMIT files 3-60  
XSUB active I-10

## Z

Zero page locations 5-8

^ meaning CTRL 2-13, 2-31  
↵ : meaning RETURN 2-16  
? as error message in CP/M I-1, 2-52