

## warm boot

The processing of reloading part of the CP/M operating system into bank 0 from the system bank and initializing the various parts of CP/M. Initiated by pressing **CTRL** + **C** or the **STOP** key.

## Z-80

An 8-bit microprocessor which was developed by the Zilog Corporation of the United States and which is used as the CPU in many of today's 8-bit microcomputers.

# Index

## A

ABORTED, G-1  
AC adapter, 1-4  
Acoustic coupler, 4-16  
    connection, 4-16  
A/D conversion, 4-9  
Alarm function, 2-48  
ALARM, 2-49  
    setting, 2-49  
ALARM string, 2-50  
Arrow keys, 2-13, 2-28  
Alphanumeric keys, 2-13  
ASCII codes, D-1  
AUTO POWER OFF time, 2-61, 5-2  
Autostart, 2-48  
AUTOST, C-25  
AUTOSTART, 2-57  
AUTOSTART string, 2-57, 2-59

## B

BAD DELIMITER, G-2  
Bad load, G-2  
Bank read current, C-14  
Bar code reader, 4-15  
BASIC, 1-20, 2-7  
    from the MENU, 2-7, 2-35, 2-45  
    restarting from CP/M command line, 2-40, 2-41  
    setting parameters, 2-59  
Basic Disk Operating System (BDOS), 1-22  
Battery, 2-89  
    charging, 2-89  
    charge Time, 2-9  
    installation, 2-1, 2-90  
    replacing, 2-90  
BDOS, 1-22  
Bdos error on d:, G-2  
Bdos error on d: bad sector, G-2  
Bdos error on d: file R/O, G-2  
Bdos error on d: select, G-2  
BEEP subroutine, C-8

BIOS, C-1  
    subroutine functions, Appendix C  
    table of entry addresses, C-1  
BOOT subroutine, C-3  
Break "x" at c, G-2

## C

Cable interface, Appendix F  
CALLX subroutine, C-22  
Cannot close, G-3  
Cannot read, G-3  
CAPS LOCK, 2-17  
CAPS LED 2-17  
Cartridge  
    digital multimeter, 4-9  
    options, 4-1  
    printer, 4-10  
    RAM, 4-4  
    ROM, 4-5  
    universal, 4-8  
CCP, 1-21  
Central processor units, 1-12  
Change device assignments, 5-6  
Changing character sets, 5-4, A-6  
Changing disks, 5-6  
Changing parameters (see System Display and CONFIG), 2-48, 2-87, 5-1  
Changing ROM, 1-17  
Changing Tapes, 2-82, 2-84  
Character set (see also DIP switch setting), A-6, D-1  
Charging battery, 1-11, 2-89  
CHARGE BATTERY, 1-11, 2-89  
Charge time, 2-90  
Checksum error, G-3  
COM file, 1-20  
Command file, 1-20  
Command buffer overflow, G-3  
Command too long, G-4  
Communications, 3-9  
CONFIG program, 5-1  
    parameters changed by, 5-1  
CONIN subroutine, C-3  
CONOUT subroutine, C-4  
Console Command Processor(CCP), 1-22  
CONST subroutine, C-3  
CONTINUE, C-26  
Continue mode, 2-10, 2-12

Copying files, see PIP  
Correct error, G-4  
Counter of tape, 2-85  
CP/M, 1-19  
    built in commands, 2-72  
    function keys assignments, 5-2  
    program utilities, 5-1  
CP/M command line, 2-39  
    and MENU, 2-32, 2-38  
    keyboard characters accepted by, 2-16  
    printing from, 5-22  
    turning to from MENU, 2-27  
CTRL key, 2-23, 3-29  
CTRL key used to switch off in continue mode, 2-12  
CTRL-C, 2-68  
    and warm starts, 2-68  
CTRL-HELP, 2-23  
CTRL-M, 2-53  
CTRL-STOP, 2-23  
Cursor changing, 5-4  
Cursor keys, 2-28  
Cursor type, 5-4

## D

Date setting, 2-5, 5-5  
Day setting, 2-5, 2-6  
Destination is R/O, G-4  
DIP switch, 4-12, 4-18  
DIR, 2-73  
Directory full, G-5  
Directory of disk, 2-73  
Disk assignments, 2-69, 5-6, C-5  
Disk drive allocation, 2-69  
Disk drive connection, 4-14  
Disk full, G-4  
Disk read error, G-4  
Disk write error, G-4  
Displaying contents of a file using TYPE, 2-79  
Display does not appear, 2-11  
Display screen, 1-16  
DIRINIT, 2-86  
Drive names, 2-69

## E

ERA, 2-75  
Erasing files from directory, 2-75  
  of microcassette tape, 2-86  
Error bad parameter, G-4  
Error cannot open source, G-5  
Error cannot close file, G-5  
Error cannot open source, G-5  
Error disk read, G-5  
Error disk write, G-5  
Error inverted load address, G-5  
Error no more directory space, G-5  
Error on line nn, G-5  
ESC key, 2-23  
Extension to files, 1-19

## F

Files and Filenames, 1-19, 2-69  
  characters allowed, 1-19  
  storage devices, 2-69  
File exists, G-5  
File is read only, G-6  
File not found, G-6  
Filename required, G-6  
File types on MENU, 2-44  
FILINK, 5-13  
Floppy Disk  
  drives, 2-69, 5-6  
  connection, 3-4, 4-4  
Folding legs, 1-4  
Format RAM disk, 2-6  
FREE lamp, 2-82  
Function keys, 2-22

## G

GETPFK subroutine, C-22  
GRPH key, 2-20  
Graphics  
  characters, 2-20, D-1

## H

hhhh? = dd error, G-6  
Halting the computer temporarily, 2-23  
HELP, 2-23  
Hide files on directory, 5-36  
HOME key, 2-30  
HOME disk subroutine in BIOS, C-4

## I

Initialization, 2-4, 2-28  
Initialization process, 2-5  
INS, 2-27  
Inserting battery, 2-89  
Insufficient memory, G-6  
Interfacing to other devices, 3-1  
International characters, A-6  
Invalid error messages, G-6, G-7  
Item keyboard, 1-15, 2-14, 2-25  
  installing, 4-11  
Item keys, 2-25

## J

JUMPX subroutine, C-22

## K

Keyboard, 2-13  
  changing, 4-11  
  layouts, 2-26  
  operation, 2-15  
  overlay, 2-25

## L

Legs positioning, 1-4  
LCD (Liquid Crystal Display), 1-16  
  release button, 1-3  
  view angle, 1-3  
LDIRX subroutine, C-21  
LED, 2-15, A-1

LIST subroutine, C-4  
LISTST subroutine, C-6  
LOADX subroutine, C-21  
Logical and physical devices, 5-6  
tables, 2-69

## M

Main processor, 1-12  
MASKI subroutine, C-20  
MCT, 2-85  
MCMTX subroutines, C-24  
Memory Map, Appendix B  
MEMORY, C-14  
MENU  
    screen, 2-10, 2-32, 2-35, 2-47  
    command line, 2-35  
    header, 2-35, 2-47  
    reverting to CP/M command line, 2-10  
    setting files types to be displayed, 2-45  
    termination of, 2-44  
    using, 2-35  
    using WAKE and AUTOSTART strings with, 2-49  
Microcassette, 2-42, 2-82, 4-7  
    BASIC and, 2-83  
    care of, 2-84  
    changing tapes, 2-82  
    counter, 2-86  
    directory, 2-82, 2-83  
    directory initialization, 2-86  
    drive name, 2-82  
    manual setting, 2-85  
    mode, 2-87  
    mounting, 2-82, 2-86  
    non-stop and stop modes, 2-87  
    removing, 2-82, 2-86  
    stop, 2-86  
    tape format, B-3  
    verify and non verify mode, 2-88  
Microcassette I/O System (MIOS), 1-22  
Microcassette Tape Operating System (MTOS), 1-22  
MIOS, 1-22  
MOUNT, see under Microcassette  
MTOS, 1-22

## N

No directory space, G-7  
NO FILE, G-8  
No space, G-8  
No sub file present, G-8  
Non-stop mode of microcassette, 2-87  
Not deleted, G-8  
Not found, G-8  
NUM, 2-19  
Numeric keys, 2-27  
Numeric mode, 2-19

## O

Operating systems, 1-18  
Operating the Computer, Chapter 2

## P

PAUSE, 2-23  
PF keys, 2-22  
PIP, 5-21  
    optional parameters, 5-24  
    with printer, 5-22  
Power failure, 2-12  
POWEROFF routine, C-25  
Power on automatically, see WAKE  
Power off automatically, 2-61  
Power BIOS subroutines, C-25  
Power switch, 1-6, 2-10  
Precautions on using the AC adapter, 2-89  
Printer, 4-12  
    adapter, 4-13  
    ASCII codes, D-1  
    cable, 4-13  
    cartridge, 4-10  
    interface, 3-18  
    output port, 4-12  
    selecting, 4-12  
Printing  
    from CP/M command line, 2-68  
    contents of a file using PIP, 5-23  
    contents of a file using TYPE, 2-79  
Programmable function keys, 2-22  
    and CP/M, 2-22, 5-2  
    and Microcassette Tape, 2-86

Protecting files  
  make Read/Only, 5-34  
  removing protection, 5-35  
PSET subroutine, C-7  
PUNCH subroutine, C-4  
PUTPFK subroutine, C-23

## Q

Quit not found, G-9

## R

RAM DISK, 1-13, 2-69, 4-17, 5-7  
  external, 4-17  
  default, 2-6  
  format, 2-62  
RDVRAM subroutine, C-24  
READ subroutine, C-6  
READER subroutine, C-4  
READSW, C-24  
Receiving files, 5-15  
Record too long, G-9  
REN, 2-77  
Renaming files, 2-77  
Resetting the system, 1-6  
Reset summary table, 2-63  
Reset sub CPU, 2-63  
RESIDENT, C-25  
Restart mode, 2-11  
Restarting the system, 2-63  
ROM capsule  
  changing, 2-93, 4-5  
  formats, 1-17  
RS-232C, 3-5, 5-13, 5-41  
  cables, 3-6  
  changing parameters, 5-9  
  communications with, 3-9  
  default settings, 5-9  
  and printer, 4-12  
  pin assignments, 3-7, 3-10, 3-11, 3-13  
RSIOX subroutines, C-14  
  RSIOX(CLOSE), C-17  
  RSIOX(CTLIN), C-18  
  RSIOX(ERSTS), C-19

RSIOX(GET), C-17  
RSIOX(INSTS), C-17  
RSIOX(OPEN), C-15  
RSIOX(OUTST), C-17  
RSIOX(PUT), C-18  
RSIOX(SENS), C-19  
RSIOX(SETCTL), C-18

## S

SAVE, 2-78  
Screen Dump, 2-48, 2-61  
Screen printing - halting, 2-61  
SCRN key, 2-31  
SCRNDUMP subroutine, C-7  
SECTRAN subroutine, C-7  
SELDSK subroutine, C-5  
Sending files, 5-14  
Serial interface, 3-4, 4-12  
  connector, 3-5  
  pin assignments, 3-5  
SETDMA subroutine, C-6  
SETSEC subroutine, C-6  
SETTRK subroutine, C-5  
Shift-in / Shift-out (SI/SO), 3-16  
Slave processor, 1-8  
Space on disk, 5-39  
Speaker, 3-1  
  BIOS subroutine, C-8  
  external jack location, 3-1  
Special keys, 2-27  
Start not found, G-9  
Starting up, 2-10  
STAT, 5-32  
  summary of commands, 5-40  
STOP key, 2-23, 2-29  
Stop mode of microcassette, 2-87  
STORX subroutine, C-21  
System Bank, 1-12  
System Bus Interface, 3-20, A-5  
System Display, 2-11, 2-42  
  parameters changed by, 2-44  
System file not accessible, G-9  
System prompt, 2-39

## T

TERM, 5-41  
Terminal mode, 5-41  
TIMEDAT  
    clock functions, C-9  
    TIMEDAT(ALARM DISABLE), C-12  
    TIMEDAT(ALARM ENABLE), C-12  
    TIMEDAT(READ ALARM), C-13  
    TIMEDAT(READ TIME), C-11  
    TIMEDAT(SET ALARM), C-12  
    TIMEDAT(SET TIME), C-11  
Time setting, 2-5, 5-5  
Too many files, G-9  
Tracking mode, 2-67  
TYPE, 2-79

## U

Upper case, 2-17  
Use: STAT error, G-10  
USER BIOS, 1-23, 2-43, 5-7  
USERBIOS subroutine, C-25  
USER, 2-80  
Utilities, 5-1  
Utility ROM, Chapter 5

## V

Verify and non-verify modes of microcassette, 2-88  
Verify error, G-10  
Virtual screen, 2-65  
    types of scrolling, 2-67

## W

WAKE, 2-52  
    setting, 2-52  
Warm start, 2-10  
WBOOT, C-3  
    how to find, C-2  
Wildcards  
    and ALARM setting, 2-56  
    and CP/M files, 2-70  
Winding tape, 2-85

Window on virtual screen, 2-65  
    maximum type, 2-66  
WRITE subroutine, C-6

## X

XON/XOFF, 3-17

? as error message in CP/M, G-1