

warm boot

The processing of reloading part of the CP/M operating system into bank 0 from the system bank and initializing the various parts of CP/M. Initiated by pressing **CTRL** + **C** or the **STOP** key.

Z-80

An 8-bit microprocessor which was developed by the Zilog Corporation of the United States and which is used as the CPU in many of today's 8-bit microcomputers.

Index

A

ABORTED, G-1
AC adapter, 1-4
Acoustic coupler, 4-16
 connection, 4-16
A/D conversion, 4-9
Alarm function, 2-48
ALARM, 2-49
 setting, 2-49
ALARM string, 2-50
Arrow keys, 2-13, 2-28
Alphanumeric keys, 2-13
ASCII codes, D-1
AUTO POWER OFF time, 2-61, 5-2
Autostart, 2-48
AUTOST, C-25
AUTOSTART, 2-57
AUTOSTART string, 2-57, 2-59

B

BAD DELIMITER, G-2
Bad load, G-2
Bank read current, C-14
Bar code reader, 4-15
BASIC, 1-20, 2-7
 from the MENU, 2-7, 2-35, 2-45
 restarting from CP/M command line, 2-40, 2-41
 setting parameters, 2-59
Basic Disk Operating System (BDOS), 1-22
Battery, 2-89
 charging, 2-89
 charge Time, 2-9
 installation, 2-1, 2-90
 replacing, 2-90
BDOS, 1-22
Bdos error on d:, G-2
Bdos error on d: bad sector, G-2
Bdos error on d: file R/O, G-2
Bdos error on d: select, G-2
BEEP subroutine, C-8

BIOS, C-1
 subroutine functions, Appendix C
 table of entry addresses, C-1
BOOT subroutine, C-3
Break "x" at c, G-2

C

Cable interface, Appendix F
CALLX subroutine, C-22
Cannot close, G-3
Cannot read, G-3
CAPS LOCK, 2-17
CAPS LED 2-17
Cartridge
 digital multimeter, 4-9
 options, 4-1
 printer, 4-10
 RAM, 4-4
 ROM, 4-5
 universal, 4-8
CCP, 1-21
Central processor units, 1-12
Change device assignments, 5-6
Changing character sets, 5-4, A-6
Changing disks, 5-6
Changing parameters (see System Display and CONFIG), 2-48, 2-87, 5-1
Changing ROM, 1-17
Changing Tapes, 2-82, 2-84
Character set (see also DIP switch setting), A-6, D-1
Charging battery, 1-11, 2-89
CHARGE BATTERY, 1-11, 2-89
Charge time, 2-90
Checksum error, G-3
COM file, 1-20
Command file, 1-20
Command buffer overflow, G-3
Command too long, G-4
Communications, 3-9
CONFIG program, 5-1
 parameters changed by, 5-1
CONIN subroutine, C-3
CONOUT subroutine, C-4
Console Command Processor(CCP), 1-22
CONST subroutine, C-3
CONTINUE, C-26
Continue mode, 2-10, 2-12

Copying files, see PIP
Correct error, G-4
Counter of tape, 2-85
CP/M, 1-19
 built in commands, 2-72
 function keys assignments, 5-2
 program utilities, 5-1
CP/M command line, 2-39
 and MENU, 2-32, 2-38
 keyboard characters accepted by, 2-16
 printing from, 5-22
 turning to from MENU, 2-27
CTRL key, 2-23, 3-29
CTRL key used to switch off in continue mode, 2-12
CTRL-C, 2-68
 and warm starts, 2-68
CTRL-HELP, 2-23
CTRL-M, 2-53
CTRL-STOP, 2-23
Cursor changing, 5-4
Cursor keys, 2-28
Cursor type, 5-4

D

Date setting, 2-5, 5-5
Day setting, 2-5, 2-6
Destination is R/O, G-4
DIP switch, 4-12, 4-18
DIR, 2-73
Directory full, G-5
Directory of disk, 2-73
Disk assignments, 2-69, 5-6, C-5
Disk drive allocation, 2-69
Disk drive connection, 4-14
Disk full, G-4
Disk read error, G-4
Disk write error, G-4
Displaying contents of a file using TYPE, 2-79
Display does not appear, 2-11
Display screen, 1-16
DIRINIT, 2-86
Drive names, 2-69

E

- ERA, 2-75
- Erasing files from directory, 2-75
 - of microcassette tape, 2-86
- Error bad parameter, G-4
- Error cannot open source, G-5
- Error cannot close file, G-5
- Error cannot open source, G-5
- Error disk read, G-5
- Error disk write, G-5
- Error inverted load address, G-5
- Error no more directory space, G-5
- Error on line nn, G-5
- ESC key, 2-23
- Extension to files, 1-19

F

- Files and Filenames, 1-19, 2-69
 - characters allowed, 1-19
 - storage devices, 2-69
- File exists, G-5
- File is read only, G-6
- File not found, G-6
- Filename required, G-6
- File types on MENU, 2-44
- FILINK, 5-13
- Floppy Disk
 - drives, 2-69, 5-6
 - connection, 3-4, 4-4
- Folding legs, 1-4
- Format RAM disk, 2-6
- FREE lamp, 2-82
- Function keys, 2-22

G

- GETPFK subroutine, C-22
- GRPH key, 2-20
- Graphics
 - characters, 2-20, D-1

H

- hhhh? = dd error, G-6
- Halting the computer temporarily, 2-23
- HELP, 2-23
- Hide files on directory, 5-36
- HOME key, 2-30
- HOME disk subroutine in BIOS, C-4

I

- Initialization, 2-4, 2-28
- Initialization process, 2-5
- INS, 2-27
- Inserting battery, 2-89
- Insufficient memory, G-6
- Interfacing to other devices, 3-1
- International characters, A-6
- Invalid error messages, G-6, G-7
- Item keyboard, 1-15, 2-14, 2-25
 - installing, 4-11
- Item keys, 2-25

J

- JUMPX subroutine, C-22

K

- Keyboard, 2-13
 - changing, 4-11
 - layouts, 2-26
 - operation, 2-15
 - overlay, 2-25

L

- Legs positioning, 1-4
- LCD (Liquid Crystal Display), 1-16
 - release button, 1-3
 - view angle, 1-3
- LDIRX subroutine, C-21
- LED, 2-15, A-1

LIST subroutine, C-4
LISTST subroutine, C-6
LOADX subroutine, C-21
Logical and physical devices, 5-6
tables, 2-69

M

Main processor, 1-12
MASKI subroutine, C-20
MCT, 2-85
MCMTX subroutines, C-24
Memory Map, Appendix B
MEMORY, C-14
MENU
screen, 2-10, 2-32, 2-35, 2-47
command line, 2-35
header, 2-35, 2-47
reverting to CP/M command line, 2-10
setting files types to be displayed, 2-45
termination of, 2-44
using, 2-35
using WAKE and AUTOSTART strings with, 2-49
Microcassette, 2-42, 2-82, 4-7
BASIC and, 2-83
care of, 2-84
changing tapes, 2-82
counter, 2-86
directory, 2-82, 2-83
directory initialization, 2-86
drive name, 2-82
manual setting, 2-85
mode, 2-87
mounting, 2-82, 2-86
non-stop and stop modes, 2-87
removing, 2-82, 2-86
stop, 2-86
tape format, B-3
verify and non verify mode, 2-88
Microcassette I/O System (MIOS), 1-22
Microcassette Tape Operating System (MTOS), 1-22
MIOS, 1-22
MOUNT, see under Microcassette
MTOS, 1-22

N

No directory space, G-7
NO FILE, G-8
No space, G-8
No sub file present, G-8
Non-stop mode of microcassette, 2-87
Not deleted, G-8
Not found, G-8
NUM, 2-19
Numeric keys, 2-27
Numeric mode, 2-19

O

Operating systems, 1-18
Operating the Computer, Chapter 2

P

PAUSE, 2-23
PF keys, 2-22
PIP, 5-21
optional parameters, 5-24
with printer, 5-22
Power failure, 2-12
POWEROFF routine, C-25
Power on automatically, see WAKE
Power off automatically, 2-61
Power BIOS subroutines, C-25
Power switch, 1-6, 2-10
Precautions on using the AC adapter, 2-89
Printer, 4-12
adapter, 4-13
ASCII codes, D-1
cable, 4-13
cartridge, 4-10
interface, 3-18
output port, 4-12
selecting, 4-12
Printing
from CP/M command line, 2-68
contents of a file using PIP, 5-23
contents of a file using TYPE, 2-79
Programmable function keys, 2-22
and CP/M, 2-22, 5-2
and Microcassette Tape, 2-86

Protecting files
 make Read/Only, 5-34
 removing protection, 5-35
PSET subroutine, C-7
PUNCH subroutine, C-4
PUTPFK subroutine, C-23

Q

Quit not found, G-9

R

RAM DISK, 1-13, 2-69, 4-17, 5-7
 external, 4-17
 default, 2-6
 format, 2-62
RDVRAM subroutine, C-24
READ subroutine, C-6
READER subroutine, C-4
READSW, C-24
Receiving files, 5-15
Record too long, G-9
REN, 2-77
Renaming files, 2-77
Resetting the system, 1-6
Reset summary table, 2-63
Reset sub CPU, 2-63
RESIDENT, C-25
Restart mode, 2-11
Restarting the system, 2-63
ROM capsule
 changing, 2-93, 4-5
 formats, 1-17
RS-232C, 3-5, 5-13, 5-41
 cables, 3-6
 changing parameters, 5-9
 communications with, 3-9
 default settings, 5-9
 and printer, 4-12
 pin assignments, 3-7, 3-10, 3-11, 3-13
RSIOX subroutines, C-14
 RSIOX(CLOSE), C-17
 RSIOX(CTLIN), C-18
 RSIOX(ERSTS), C-19

RSIOX(GET), C-17
RSIOX(INSTS), C-17
RSIOX(OPEN), C-15
RSIOX(OUTST), C-17
RSIOX(PUT), C-18
RSIOX(SENS), C-19
RSIOX(SETCTL), C-18

S

SAVE, 2-78
Screen Dump, 2-48, 2-61
Screen printing - halting, 2-61
SCRN key, 2-31
SCRNDUMP subroutine, C-7
SECTRAN subroutine, C-7
SELDSK subroutine, C-5
Sending files, 5-14
Serial interface, 3-4, 4-12
 connector, 3-5
 pin assignments, 3-5
SETDMA subroutine, C-6
SETSEC subroutine, C-6
SETTRK subroutine, C-5
Shift-in / Shift-out (SI/SO), 3-16
Slave processor, 1-8
Space on disk, 5-39
Speaker, 3-1
 BIOS subroutine, C-8
 external jack location, 3-1
Special keys, 2-27
Start not found, G-9
Starting up, 2-10
STAT, 5-32
 summary of commands, 5-40
STOP key, 2-23, 2-29
Stop mode of microcassette, 2-87
STORX subroutine, C-21
System Bank, 1-12
System Bus Interface, 3-20, A-5
System Display, 2-11, 2-42
 parameters changed by, 2-44
System file not accessible, G-9
System prompt, 2-39

T

TERM, 5-41
Terminal mode, 5-41
TIMEDAT
 clock functions, C-9
 TIMEDAT(ALARM DISABLE), C-12
 TIMEDAT(ALARM ENABLE), C-12
 TIMEDAT(READ ALARM), C-13
 TIMEDAT(READ TIME), C-11
 TIMEDAT(SET ALARM), C-12
 TIMEDAT(SET TIME), C-11
Time setting, 2-5, 5-5
Too many files, G-9
Tracking mode, 2-67
TYPE, 2-79

U

Upper case, 2-17
Use: STAT error, G-10
USER BIOS, 1-23, 2-43, 5-7
USERBIOS subroutine, C-25
USER, 2-80
Utilities, 5-1
Utility ROM, Chapter 5

V

Verify and non-verify modes of microcassette, 2-88
Verify error, G-10
Virtual screen, 2-65
 types of scrolling, 2-67

W

WAKE, 2-52
 setting, 2-52
Warm start, 2-10
WBOOT, C-3
 how to find, C-2
Wildcards
 and ALARM setting, 2-56
 and CP/M files, 2-70
Winding tape, 2-85

Window on virtual screen, 2-65
 maximum type, 2-66
WRITE subroutine, C-6

X

XON/XOFF, 3-17

? as error message in CP/M, G-1